

Pulptec[™] SBT-2400 Static Blade Consistency Transmitter



Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design, and manufacturing. BTG shall have no liability for any error or damages of any kind resulting from the use of this document. ©BTG 2006.

BTG Pulp & Paper Sensors AB P.O. Box 602 SE-661 29 Säffle Sweden Phone: +46 533 426 00 www.btg.com

Table of contents

1	Product Introduction1			
	1.1	System Description	1	
	1.2	Technical Data	2	
	1.3	Dimensions and Mounting	4	
	1.4	Type Sign Explanation	5	
2	Safety Ins	tructions	7	
	2.1	General	7	
	2.2	Conventions	8	
	2.3	Safety Regulations	9	
	2.3.1	Safety Regulations for Installation	9	
	2.3.2	Safety Regulations for Service	9	
	2.4	CE-declaration	0	
3	Installatio	n Instructions11	1	
	3.1	Unpacking	1	
	3.2	Assembly of Product Parts12	2	
	3.2.1	Mount the Blade	2	
	3.2.2	Mount the Deflector 12	2	
	3.3	Welding Instructions1	3	
	3.3.1	Weld-on Stud	3	
	3.3.2	Pipe Deflector	5	
	3.4	Mounting Instructions1	6	
	3.5	Connection Instruction1	7	
	3.5.1	Electrical Connection 1	7	
	3.5.1.1	2-wire Connection 1	7	
	3.5.1.2	3- and 4-wire Connection	8	
	3.5.1.3	Mounting of Optional Accessories	9	
	3.0	Mounting of Optional Accessories	U C	
	3.6.1	Nounting of Fieldbus Interface		
	3.0.Z		U	

4	Operating Instructions21			
	4.1	Commissioning	I	
	4.1.1	Conventions	I	
	4.1.2	Transmitter Setup	2	
	4.1.3	Set Lab Sampling Time 22	2	
	4.2	Operations with JCT-1200	3	
	4.2.1	View Measurement 23	3	
	4.2.2	Change Range	3	
	4.2.3	Calibration	3	
	4.2.3.1	Single-point Calibration 24	1	
	4.2.3.2	Multi-point Calibration 25	5	
	4.2.4	Take New Sample Values 26	3	
	4.2.4.1	Take New Sample Values from the JCT-1200	3	
	4.2.4.2	Take New Sample Values from Sample Switch	5 	
	4.2.5	Enter Lab Sample Values	5 	
	4.2.6	Calculate New Calibration Constants) -	
	4.2.7		, -	
	4.2.8		, ,	
	4.2.9		, 7	
	4.2.10		, _	
	4.3		3	
	4.3.1	Conventions	3	
	4.3.2		•	
	4.3.2.1		۶ ۲	
	4.3.3	Select SB1-2400 Program	۶ ۲	
	4.3.4	View Measurement/Read Data	۶ ۲	
	4.3.5	Take New Sample Values	ן ר	
	4.3.0	Enter Lab Sample Values	ן ר	
	4.3.7	Use Calculated Values in Measurement	י ר	
	4.3.8	Dise Sample Values in Calculation) 1	
	4.3.9	Change Transmitter Specifications	1	
	4.3.10 A A		ו כ	
	4.4		-	

5	Service In	structions
	5.1	General
	5.1.1	Use of Equipment
	5.1.2	Basic Conditions
	5.2	Maintenance Routines
	5.2.1	Changing O-ring Seals
	5.2.1.1	Wetted Part
	5.2.1.2	Housing
	5.2.1.3	Measuring Module
	5.2.1.4	Housing Cover
	5.2.2	Analog Out Calibration
	5.2.2.1	Analog Out Calibration with JCT-1200
	5.2.2.2	Analog Out Calibration using SPC-1000
	5.2.3	Calibration of Transmitter
	5.2.3.1	Basic Force Calibration with JCT-1200 37
	5.2.3.2	Basic Force Calibration with SPC-1000
	5.2.4	Trim Raw Signal using SPC-1000 38
	5.3	Repair
	5.3.1	Transmitter Replacement
	5.3.1.1	Remove the Transmitter from Process Pipe
	5.3.1.2	Change the O-ring Seal 39
	5.3.1.3	Mount the Transmitter 39
	5.3.2	Blade and Deflector Replacement 40
	5.3.2.1	Remove the Blade and Deflector 40
	5.3.2.2	Mount the Blade and Deflector 41
	5.3.2.3	Mount Transmitter 41
	5.3.3	Circuit Board Replacement 42
	5.3.3.1	Remove the Circuit Board 42
	5.3.3.2	Mount the Circuit Board
	5.3.4	Measuring Module Replacement 44
	5.3.4.1	Remove the Measuring Module
	5.3.4.2	Change the O-ring Seal
	5.3.4.3	Mount the Measuring Module
	5.3.5	Measuring Module O-Ring Seal Replacement
	5.3.5.1	Remove the O-Ring Seal
	5.3.5.2	Change Transmitter Chasifications
	5.3.6	Change Transmitter Specifications
	5.3.7	Change Connector
	5.4	I roubleshooting

6	Parts List	
	6.1 6.2	Spare Parts
7	Appendix	
	7.1	Process Site Selection
	7.1.1	Straight Pipe Length Calculation
	7.1.2	Vertical Pipe Installation
	7.1.3	Horizontal Pipe Installation
	7.1.4	Multiple Bend Piping Installation 59
	7.1.5	Valve and Pump Influences 60
	7.2	Flow Guide and Pipe Deflector Installation
	7.2.1	Pipe Deflector Installation 61
	7.2.2	Flow Guide Installation 62
	7.2.3	Reverse Flow Installation 62
	7.3	Dilution
	7.4	Dimensioning of the Dilution Water Valve
	7.4.1	Calculation Formula for Dilution Water Flow:
	7.4.2	Dimensioning of the Dilution Water Valve
	7.5	Pressure and Temperature Limits
	7.6	Menu Overview (only in English)71
	7.6.1	Measurement/Sampling71
	7.6.2	Calibrate
	7.6.3	Configure
	7.6.4	Diagnostics
	7.7	Blade Selection Guide

1 Product Introduction

1.1 System Description

The SBT-2400 is a static blade transmitter for measurement of the fiber consistency in pulp suspensions. The transmitter uses the shear force principle to measure consistency.

In applications where static blade transmitters are used, the SBT-2400 is an highly competitive alternative both in terms of performance and cost.

The shear force of a pulp suspension is depending on the strength of the fiber network, and increase with fiber consistency. As the pulp suspension flows past the SBT-2400 blade, the shear force of the pulp suspension causes the material in the measuring module to stretch. The other end of the measuring spindle moves when fiber consistency changes and this movement is measured by a differential transformer with an extremely high resolution.

The transmitter basically consists of three parts:

- blade
- measuring module
- electronics module

The measuring module consists of a measuring spindle, and a differential transformer. It is delivered as a complete unit to simplify repair. The electronics module in the transmitter contains both analogue circuitry and a microprocessor performing the smart transmitter functions. To further reduce costs, a factory renovation exchange system is provided for the critical parts.

1.2 Technical Data

General

Manufacturer BTG, Säffle, Sweden

Quality assurance In accordance with ISO 9001.

Product safety Fulfills all relevant CE-directive requirements and all Australian **c** requirements.

Functional Specifications

Measuring Range Approx. 1.5 - 16% pulp consistency depending on fiber type. 4 different calibration sets.

Analog Output Signal

4 - 20 mA. Current limited to 21 mA. Superimposed signal according to standard HART® protocol.

Fieldbus

Profibus PA (optional) Foundation Fieldbus (optional)

Damping

3 - 99 s

Process Specifications

Flow Limits 0.5 - 5 m/s (1.64 - 16.4 ft/sec.) Depending on blade type, fiber type, and consistency.

Process Temperature Limits Max. 100 °C (212 °F)

Ambient Temperature Limits Max. 60 °C (140 °F)

Support System Specifications

Connection

Delivered with BTG junction box, JCT-1200, as standard.

Power Supply

20 - 35 V DC (2-wire supply)

Performance Specifications

Repeatability

0.01% Cs (at 3% in the range 1.8-4.3%) Reference pulp: Softwood chemical pulp

Pressure Effect

0.02% Cs*/bar

Process Temperature Effect

0.7%/10°C of output reading (0.02% Cs*)

Hysteresis 0.007% Cs*

Load Limitation Max. 1120 Ω for supply voltage, 35 V DC.

Load Dependency

<0.01 mA (100 - 850 Ω) (at 3% Cs in the range 1.8 - 4.3%) Reference pulp: Softwood chemical pulp

Physical Specifications

Mounting Weld-on stud for pipeline.

Storage Temperature Min. -20°C (-4°F), Max. 70°C (158°F)

Degree of Protection

Equivalent to IP65/NEMA 4 Installation category: III Pollution degree: 2

Materials

Wetted parts: Stainless steel EN14404 or 254 SMO (option for MC transmitters) Housing: Aluminum, painted with epoxy/polyurethane Static O-rings: Fluor rubber or EPDM

Weight

3.9 kg (8.6 lbs)

Connection

Cable, UL/ETL approved, 10 m (33 ft.). Delivered with BTG Junction Box, JCT-1200. Other lengths on request.

Resonance Frequency

Resonance can occur between 450 and 550 Hz

Pressure Rating

PN 25 (360 psi at 68 °F)

EEC Directives and Standards

According to relevant standards. See section 2.4: CE-declaration.



1.3 Dimensions and Mounting

Blade	Dim. X	Dim. Y	Consistency	Min. Pipe Diameter
А	240 mm (9.5")	93 mm (3.7")	1.5% - 7%	100 mm (4")
В	220 mm (8.7")	93 mm (3.7")	2% - 8%	100 mm (4")
С	61 mm (2.5")	66 mm (2.6")	4% - 16%	80 mm (3.1")
D	240 mm (9.5")	93 mm (3.7")	1.5% - 8%	100 mm (4")

1.4 Type Sign Explanation



- 9. Current
- 10. Voltage
- 11. Warning sign

The SBT-2400 is designed for industrial use. Installation, handling and service must only be carried out by trained and authorized personnel and according to relevant standards. Read the manual for detailed information and pay special attention to the warning signs!

1.4 - Type Sign Explanation

2 Safety Instructions

2.1 General

These safety regulations are based on a risk analysis carried out in accordance with the requirements of relevant CE directions in order to comply with European standards for CE marking.

In practice, an operating consistency transmitter is only hazardous while covers are removed during installation and service.

Read these safety regulations before installing the transmitter. Follow the regulations when installing the transmitter, starting up and when carrying out service. Use warning signs for safety information!

Mounting parts, such as the weld-in stud, are dealt with in accordance with the pressure vessel standards of the countries in question.

Always take precautions when handling equipment in pressurized pipes.

All installation, operation, service, and other handling must be carried out by trained and authorized personnel and according to valid standard.

NOTE!

Follow this manual for all installation, operation, and service.

NOTE!

For good personal and functional safety: Use only parts which have been manufactured or approved by BTG.

2.2 Conventions

The following conventions are used in this manual:

• DANGER!

A **DANGER!** admonition is used when there is a hazard with a risk for *injury* or possible death to a person.

WARNING!

A **WARNING!** admonition is used when there is a risk for *damage* to program, device, machine, sampler and so on.

• CAUTION!

A **CAUTION!** admonition is used when there is a risk for *system failure, service interruption, disturbances* to plant operation, a measuring application and so on.

The admonitions above are hierarchic. A **DANGER!** admonition includes the possibility of both a **WARNING!** and a **CAUTION!** admonition.





2.3 Safety Regulations

2.3.1 Safety Regulations for Installation

All welding must take place in accordance with current standards and regulations.

All handling of electrical units must take place in accordance with current standards and regulations.

2.3.2 Safety Regulations for Service

All handling of electrical units must take place in accordance with current standards and regulations.

2.4 CE-declaration

When using the units in other combinations than tested for, BTG can not guarantee the CE directive conformity.

The units in combination with customer installed external devices may conform with EMC and safety requirements when properly installed and using an adequate CE marked equipment.

The system operator is responsible for the CE directive conformity. The conformity must be verified by inspection.



3 Installation Instructions

3.1 Unpacking

The following items can be included in an SBT-2400 delivery:



- 1. 1 x static blade transmitter, SBT-2400
- 2. 1 x blade
- 3. 1 x deflector
- 4. 1 x 4 mm Allen key
- 5. 1 x set of bolts for the blade (not shown in figure)
- 6. 1 x cd with documentation (not shown in figure)
- 7. 1 x weld-in stud, complete with coupling and blind flange
- 8. 1 x welding profile (not shown in figure)
- 9. 1 x welding instruction (not shown in figure)
- 10. 1 x flow guide/pipe deflector
- 11. 1 x junction box, JCT-1200 (optional, not shown in figure)
- 12. 1 x cable with connector in one end (optional)
- 13. 1 x printed manual (optional, not shown in figure)
- 14. 1 x welding jig (optional, not shown in figure)
- 15. 1 x calibration kit (optional)
- 16. 1 x fieldbus interface, FCI-family (optional, not shown in figure)

3.2 Assembly of Product Parts

3.2.1 Mount the Blade

See section 5.3.2.2 on page 41.

3.2.2 Mount the Deflector

See section 5.3.2.2 on page 41.

3.3 Welding Instructions

3.3.1 Weld-on Stud

The transmitter is mounted in a stud that is welded to the process piping. Before the weld-on stud is welded on the pipe, the stud must be profiled in order to fit the pipe dimension. This is necessary to avoid intrusion into the pipe.

NOTE!

The distance from the stud flange to the inner diameter of the pipe must always be kept to 22 mm. The measuring result will not be reliable if the transmitter has more than $\pm 0.5^{\circ}$ angle deviation.









NOTE!

Insert a piece of welding wire into each of the two holes in the deflector before inserting it into the pipe. This will hold the deflector at the correct height during welding.

3.4 Mounting Instructions

Consumables required:

Silicon grease

NOTE!

Before transmitter setup is done, a shear force trim must be performed.

NOTE!

If the O-ring tends to fall out, use silicon grease to keep the O-ring in the groove.



NOTE!

Align the transmitter with the process piping center line. IMPORTANT! Place a ruler on the flat aligning area to position the transmitter. The maximum aligning deviation allowed is $\pm 0.5^{\circ}$

3.5 Connection Instruction

3.5.1 Electrical Connection

For information on how to connect the transmitter to a BTG junction box, JCT-1200, see the *Connection Instructions* in the JCT-1200 user manual.

3.5.1.1 2-wire Connection

NOTE!

Default configuration from BTG is a 2-wire setup.





3.5.1.2 3- and 4-wire Connection

3.6 Mounting of Optional Accessories

3.6.1 Mounting of Fieldbus Interface

See the Installation Instruction chapter in the user manual for appropriate FCI-family product.

3.6.2 Mounting of Junction Box JCT-1200

See the Installation Instruction chapter in the JCT-1200 user manual.

3.6 - Mounting of Optional Accessories

4 Operating Instructions

4.1 Commissioning

4.1.1 Conventions

To navigate in the SBT-2400 software, three function keys (**F1**, **F2**, and **F3**) are used, along with two scroll keys (**Up** and **Down**) on the JCT-1200. The function keys have different functions depending on where in the structure of the software the user is. In the following instructions the displayed item is shown with the function key shown in a parenthesis. Example: **Enter (F2)**

The scroll keys are just shown using bold text only. Example: Use the **Up/Down** keys to select appropriate parameter.

NOTE!

For more information on the menu system, see section 7.6: *Menu Overview* (only in English).



The **Up/Down** keys are also used to change parameter values. For instance, in the basic calibration window, mark the **Offset** option by using the **Up/Down** keys. Then press **Edit (F3)**. The cursor will start flashing. By using the **=> (F2)** key and the **Up/Down** keys, the value can be changed. To save the new value, press **OK (F1)**.

4.1.2 Transmitter Setup

The purpose of the setup is to set the mounted transmitter into operation with a basic calibration. This concerns the mounting position, blade type, tag number, pulp type calibration constants and the span of the output signal.

NOTE!

Before transmitter setup is done, a shear force trim must be performed. See section 5.2.3: *Calibration of Transmitter*.

- 1. Power up the JCT-1200.
- 2. Press Menu (F1), step down through the menu tree to the Shear force trim window, note the Raw signal value.
- 3. Select the Mounted+air option and press Edit (F3).
- 4. Enter the Raw signal value and press OK (F1).
- 5. Press Menu (F1), step down through the menu tree to the General settings window, select the Blade type option and press Edit (F3).
- 6. Enter the correct blade. Press **OK (F1)**.
- 7. Select Tag, press Edit (F3), enter the correct tag. Press OK (F1).
- 8. Press the **Menu (F1)** key twice to step up through the menu tree. The main menu window opens.
- 9. Go to the **Basic calibration** window for **Range 1**, select the **K1** option and press **Edit (F3)**.
- Enter the appropriate value from the calibration table. See section 7.7: Blade Selection Guide. Press OK (F1).
- 11. Select the **K2** option and press **Edit (F3)**. Enter appropriate value from the same calibration table as in step 9. Press **OK (F1)**.
- 12. Select the **4mA** option and press **Edit (F3)**. Enter correct percentage for 4mA. Press **OK (F1)**.
- 13. Select the **20mA** option and press **Enter (F2)**. Enter correct percentage for 20mA. Press **OK (F1)**.
- 14. Transmitter setup is completed.

IMPORTANT!

Note all entered values and save as backup.

4.1.3 Set Lab Sampling Time

The **LabSamplTime** value should correspond to the actual time it takes to collect the lab sample from the process pipe.

- 1. Press Menu (F1), step down through the menu tree to the General settings window, select the LabSamplTime option and press Edit (F3).
- 2. Enter correct time. Press OK (F1).

4.2 Operations with JCT-1200

4.2.1 View Measurement

Select one of the three windows by pressing the Next (F2) key.

The first window shows **Cons** in a large font. The second window shows **Raw signal** in a large font. The third window shows all values in normal font.

4.2.2 Change Range

In SBT-2400 four different ranges are available. For more information, see the JCT-1200 manual. To change between the ranges, use binary input on the Range Select Inputs in the JCT-1200.

```
NOTE!
```

Only for DCS!

4.2.3 Calibration

It is easy to calibrate the SBT-2400 to the actual pulp. There is a number of calibration sets for a lot of different pulps which fits in most cases. See section 7.7: *Blade Selection Guide* for calibration constants for different pulps and different blades. If the appropriate constants are not in the guide, contact BTG service personnel for information or proceed with a multi-point calibration to calculate specific constants for your pulp.

When using the constants from the guide, a single point calibration with an offset adjustment at the target consistency will put the transmitter in a good calibrated status. A multipoint calibration with up to nine lab samples will of course make the transmitter perform even better.

Single-point calibration

A single point calibration is used with already made calibration constants to adjust for the specific pulp. Even though the pulp is listed in the Blade selection guide, every installation will differ slightly. The calibration will set an offset adjustment only.

The operation needed is to take one sample according to section 4.2.4: *Take New Sample Values* and note the consistency value from the sampling results page on the specific sample. When the laboratory test is finished the deviation can be calculated and entered as on offset in the basic calibration page.

Multi-point calibration

In some occasions there is a need for a more precise calibration. The pulp could be very different from the ones listed in section 7.7: *Blade Selection Guide* or a mix of different pulp grades. In these cases a multiple point calibration is preferred to have the SBT-2400 work as expected.

4.2.3.1 Single-point Calibration



4.2.3.2 Multi-point Calibration



4.2.4 Take New Sample Values

4.2.4.1 Take New Sample Values from the JCT-1200

- 1. Press the Sample (F3) key. The sample window opens.
- 2. Press **Start (F1)**. Wait for the confirmation window.
- 3. If the sample was successful, press Save (F2).

4.2.4.2 Take New Sample Values from Sample Switch

If an external sample switch is connected, do as follows:

- 1. Activate the sample switch. The JCT-1200 display lights up. Sampling is started.
- If there is too much signal variation during sampling, make another sample. Activate the sample switch to start a new sample. If the sample was OK, press Save (F1) on the JCT-1200.

NOTE!

Write down the sample number.

4.2.5 Enter Lab Sample Values

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **Lab calibration** window.
- 2. Select the appropriate **Sample** number, use the -> (F2) key to mark the Lab cons value. Press Edit (F3).
- 3. Enter the lab value. Press OK (F1).

4.2.6 Calculate New Calibration Constants

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **Lab calibration** window.
- 2. Select the appropriate Sample number, use the -> (F2) key to mark the On/Off column and press the On/Off (F3) key. Only if both Shear force and Lab cons have values larger than zero, it is possible to place the cursor in the On/Off column. A star indicates that the sample is used. Repeat the same procedure for each sample that will be used.

NOTE!

The maximum number of samples is nine. To select samples with higher number than displayed, use the Up/Down keys to scroll the text in the window.

- 3. Press the **Result (F1)** key. The lab calibration result window opens.
- If you want to use the new value, press Save (F2).
 If you want to use the old value, press Cancel (F3) or press Back (F1) and turn the samples off again.

4.2.7 Remove Sample Values

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **Lab calibration** window.
- Select a sample and press Edit (F3). If sample is active, select the * with the -> (F2) key and deactivate by pressing On/Off (F3).
- 3. Remove the **Sample** value and press **Delete (F3)**.
- 4. Press OK (F1).

4.2.8 Change Offset

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **Basic** calibration window.
- 2. Select Offset and press Edit (F3).
- 3. Enter the offset value. Press OK (F1).

4.2.9 View Diagnostics

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **Diagnostics** window.
- 2. View the transmitter's internal temperature, the maximum temperature exposed to the transmitter, the software version, running hours and the number of transmitter start-ups.

4.2.10 Set JCT Display Light Time

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **General** settings window.
- 2. Select the LcdBackLight option. Press Edit (F3).
- 3. Enter the number of seconds the JCT display shall stay lit after the last button is pressed. Press **OK (F1)**.

NOTE!

If the **LcdBackLight** option is set to anything but zero, the light will be activated when a button is pressed. The first time a button is pressed, the display is lit; the second time a button is pressed, the function of the button is activated

NOTE!

If a JCT with power supply is used, the display will be lit at all times.

4.3 Operations with SPC-1000

Prerequisites:

That SPC-1000 is connected to SBT-2400 through JCT-1200, and that the software communication is established.

The JCT-1200 is not equipped with power supply as standard, so verify that SPC-1000 batteries are charged before connecting to the JCT-1200.

NOTE!

The backlight function in SPC-1000 is only supported in 4-wire installations.

4.3.1 Conventions

SPC-1000 uses a touch display for software navigation. The display is divided into a grid, and different options are displayed depending on where in the software you are.

In the following instructions, the displayed options are shown with the button name in bold.

Example: Calibr.



4.3.2 Code protection

A security code can be entered to prevent unauthorized adjustment of the transmitter settings. A personal code or the general BTG code, 42 600, can be used.

4.3.2.1 Changing Your Personal Code

- 1. Press the **Send data** option. The send data window opens.
- 2. Press Turn code ON/OFF.
- Press Change code. Load old code will be displayed. Enter your old personal code (or the general BTG code). Load new code will then be displayed. Enter your new code (max 5 digits). Press Enter.

The code protection can also be deactivated/activated

Press **Code ON/OFF** so that it displays desired setting. Enter your personal code.

4.3.3 Select SBT-2400 Program

- 1. Power up the SPC-1000. The start-up screen opens.
- 2. Press the **SBT 2400** option. The main window opens.

4.3.4 View Measurement/Read Data

- 1. Press the **Read data** option. The read data window opens.
- Press the Yes option. The main window opens with updated information.
- 3. View measurement in main window.

4.3.5 Take New Sample Values

- 1. Press the **Calibr.** option. A new window opens.
- 2. Press the **Take sample menu** option. A new window opens.
- 3. Press the Edit sample option to select a memory slot to store the sample.
- 4. Press the Avrg. of xx s option to select the sampling time. A new window opens. Select the time in seconds and press the Enter/Menu option.
- 5. Press the **Take sample** option. A new window opens.
- 6. Wait for sampling to finish.
- 7. Press the Accept option to accept the sample.

NOTE!

The sample can not be used in the calculation until the lab sample value is entered.

4.3.6 Enter Lab Sample Values

- 1. Press the **Calibration** option. A new window opens.
- 2. Press the **Load lab cons** option. A new window opens.
- 3. Press the Edit sample option to select a memory slot to store the sample.
- Press the Load lab cons option to load the lab consistency. A new window opens. Select the value in percent and press the Enter/Menu option.

4.3.7 Use Calculated Values in Measurement

- 1. Press the **Calibration** option. A new window opens.
- 2. Press the **Load lab cons** option. A new window opens.
- 3. Select appropriate sample and press the ON/OFF option.

4.3.8 Use Sample Values in Calculation

- 1. Press the **Calibration** option. A new window opens.
- 2. Press the Calc. new calibr. option.
4.3.9 Remove Sample Values

- 1. Press the **Calibration** option. A new window opens.
- 2. Press the **Take sample menu** option. A new window opens.
- 3. Press the **New calibration** option. A new window opens.
- 4. Press the Yes option.

NOTE!

The entire table will be erased.

4.3.10 Change Transmitter Specifications

- 1. Press the **Configure** option. A new window opens.
- 2. Press appropriate parameter and edit the value.
- 3. Press the Send page option.

4.4 HART Communication

This transmitter uses the *HART universal command specification, revision 5.0*. The following universal commands are available:

HART Universal Command		Use in SBT-2400	Comments
0	Read unique identifier	Reads device name, HW and SW revisions, Tag name and so on	-
1	Read primary value	Reads consistency	-
2	Read primary value current and percent of range	Reads analog out in percent of range	-
3	Read dynamic variables and primary values current	Available, not used	String empty
4	Reserved	Not available	-
5	Reserved	Not available	-
6	Write polling address	Write polling addresses	-
11	Read unique identifier associated with tag	Same as command 0 but using tag as identifier.	-
12	Read message	Read message	String empty
13	Read tag, descriptor, date	Read tag, descriptor, date	-
14	Read primary variable sensor information	Available, not used	String empty
15	Read primary value output information		-
16	Read final assembly number	Available, not used	String empty
17	Write message	Available, not used. See also command 12	String empty
18	Write tag, descriptor, date	See also command 13	-
19	Write finally assembly number	Available, not used. See also command 16	String empty

5 Service Instructions

5.1 General

If the transmitter is correctly installed, service can be kept to a minimum. The transmitter is designed and built to be robust enough to withstand high mechanical impacts on the blade. However, special precautions may be needed in the event of abnormal situations occurring.

Examples of abnormal situations include:

• Excessive vibration in the pipe system

Vibration can ruin the measurement and cause abnormal wear on the transmitter. If the vibration level is too high, locate the reason and take appropriate steps to remove the vibration.

The problem can be caused by cavitation in a pump or weak process-pipe supports.

If the problem cannot be found or corrected at the source, install flexible rubber bellows in the process pipe.

Pulp contains large foreign objects or high-consistency chunks

If the pulp can contain large foreign objects, or high-consistency chunks, flow deflectors must be installed. Otherwise the blade and measuring module risk damage.

5.1.1 Use of Equipment

- The transmitter is not designed to be used as a ladder or a footstep! Do not use it as such!
- The signal cable must be correctly located and supported to avoid stress to the contact as well as to the cable.
- The contact must be correctly tightened to avoid leakage.
- To avoid signal interference, the signal cable must not be close to the high voltage power cables.
- Do not clean the transmitter using a high-pressure jet cleaner! Water may penetrate into the transmitter and damage it. Protect the transmitter from frequent flooding from sources such as a chest.
- Power must be within correct voltage range (20-35VDC) when connecting the transmitter.
 Over-voltage will ruin the electronics!

5.1.2 Basic Conditions

Ensure that suitable tools and measuring instruments are available. Certain actions require special tools from BTG. Required tools, spare parts, and consumables are listed in each service action section.

5.2 Maintenance Routines

5.2.1 Changing O-ring Seals

5.2.1.1 Wetted Part

Spare parts required:

O-ring seal

Consumable required:

(Silicon grease)

- 1. Remove the old O-ring seal from the SBT-2400.
- 2. Mount the new O-ring seal. Use silicon grease to keep it in place during installation.

5.2.1.2 Housing

Spare parts required:

O-ring seal

Tools required:

Snap ring pliers 2.5 mm allen key/hexagon spanner 4 mm allen key/hexagon spanner (Small pliers) (Wise)

Consumable required:

(Silicone grease)

- 1. Remove the blade. See section 5.3.2.1: Remove the Blade and Deflector.
- 2. Remove the housing cover.
- 3. Remove the circuit board. See section 5.3.3.1: Remove the Circuit Board.

4. Remove the 3 bolts (1) at the bottom of the transmitter housing.



- 5. Carefully extract the measuring module (2).
- 6. Remove the old O-ring seal from the housing.
- 7. Insert the new O-ring seal. If needed, use silicon grease to hold the O-ring seal in place during assembly.
- 8. Assemble in reverse order.

5.2.1.3 Measuring Module

See section 5.3.5: Measuring Module O-Ring Seal Replacement.

5.2.1.4 Housing Cover

Spare parts required:

O-ring seal

Tools required:

Snap ring pliers 2.5 mm allen key/hexagon spanner 4 mm allen key/hexagon spanner (Small pliers) (Wise)

Consumable required:

(Silicone grease)

- 1. Remove the four screws and remove the cover.
- 2. Remove the old O-ring seal from the cover.
- 3. Mount the new O-ring seal. If needed, use silicon grease to keep it in place during assembly.
- 4. Assemble in revers order.

5.2.2 Analog Out Calibration

5.2.2.1 Analog Out Calibration with JCT-1200

Tools required:

Digital Multi-meter (DMM)

- 1. Do a serial connection with a DMM to the output signal from the SBT-2400.
- 2. Press the **Menu (F1)** key, step down through the menu tree to the **Analog output trim** window.
- 3. Select the **Test output** option, press **Edit (F3)**. Enter **4** mA and press **OK** (F1).
- Press Test (F2). Note the value displayed on the DMM. The value is displayed for 30 seconds after Test (F2) is pressed.
- 5. Select the **4 mA trim** option, press **Edit (F3)**. Enter the necessary trim adjustment to trim the display value to exactly 4 mA. Press **OK (F1)**.
- Press Test (F2) again.
 Note the value displayed on the DMM.
 Repeat step 4 and step 5 until the displayed value is exactly 4 mA.
- 7. Select the **Test output** option, press **Edit (F3)**. Enter **20** mA and press **OK (F1)**.
- 8. Press **Test (F2)**. Note the value displayed on the DMM.
- 9. Select the **20 mA trim** option, press **Edit (F3)**. Enter the necessary trim adjustment to trim the display value to exactly 20 mA. Press **OK (F1)**.
- Press Test (F2) again. Note the value displayed on the DMM. Repeat step 8 and step 9 until the displayed value is exactly 20 mA.

5.2.2.2 Analog Out Calibration using SPC-1000

Tools required:

SPC-1000

- 1. Press the **Misc.** option. A new window opens.
- 2. Press the **Factory setting** option. A new window opens.
- Enter the following code: 1632 Press Enter. A new window opens.
- 4. Press the **4 mA** option. A new window opens.
- 5. To adjust the 4mA signal, press the 4 up or 4 down options. Press Enter.
- 6. Press the **20 mA** option. A new window opens.
- 7. To adjust the 20mA signal, press the **20 up** or **20 down** options. Press **Enter**.

5.2.3 Calibration of Transmitter

The factory preset for the transmitter is equal to a shear force of 0-15 N. This represents a consistency span of approximately 0 - 6% long-fiber chemical pulp and approximately 0 - 7% short-fiber chemical pulp for blade A.

A basic calibration is required when:

- The blade is changed to another type (different weight).
- The basic setting must be verified.
 - The signal does not correlate to the laboratory consistency samples.
- The blade has been exposed to a very high mechanical force.

5.2.3.1 Basic Force Calibration with JCT-1200

Tools required:	
Calibration stand Calibration weight	

Prerequisites: That the transmitter is mounted in the calibration wise with the blade pointing sideways (horizontal) and that the JCT-1200 is connected and working.

- 1. Press the **Menu (F1)** key, step down through the menu tree to the **Shear** force trim window.
- 2. Note the value for **Raw**.
- 3. Select the Blade value and press the Edit (F3) key.
- 4. Enter the noted value and press OK (F1).
- 5. Turn the transmitter with blade pointing downwards.



- 6. Place the calibration weight in the hole in the blade.
- 7. Wait until Raw signal have stabilized. Wait approx. 30 minutes.
- 8. Note the value for Raw.
- 9. Select the Blade+weight option and press the Edit (F3) key.

- 10. Enter the noted value and press OK (F1).
- 11. Remove the weight and turn the transmitter in the position that it will be mounted.
- 12. Note the value for Raw.
- 13. Select the Mounted+air option and press the Edit (F3) key.
- 14. Enter the noted value and press OK (F1).
- 15. The transmitter is now ready to be installed.

NOTE!

The Raw sig Trim is a factory set value and should normally not be changed unless measuring module have been changed.

5.2.3.2 Basic Force Calibration with SPC-1000

Prerequisites: That the transmitter is mounted in a jaw wise with the blade pointing sideways, and that the SPC-1000 is connected and working.

- 1. Press the **Configure** option. A new window opens.
- 2. Press the **Shear force trim.** option. A new window opens.
- 3. Wait until the Raw signal is stable, then press the Set min option.
- 4. Turn transmitter with the blade pointing downwards.
- 5. Hang the calibration weight on the blade.
- 6. Wait until the **Raw signal** is stable (approx. 30 minutes), then press the **Set max** option.
- 7. Press the Send page option.

5.2.4 Trim Raw Signal using SPC-1000

- 1. Press the **Misc.** option. A new window opens.
- 2. Press the **Factory setting** option. A new window opens.
- 3. Enter the following code: **1632** Press **Enter**. A new window opens.
- 4. To adjust the Raw signal, press the **Trim up** or **Trim down** options. Press **Enter**.

5.3 Repair

5.3.1 Transmitter Replacement

- Before any service is carried out, the transmitter must be carefully cleaned from pulp and other impurities.
- If the transmitter is taken to a workshop for detailed service, ensure that the workbench is clean. Particles can penetrate the differential transformer and degrade the performance.

5.3.1.1 Remove the Transmitter from Process Pipe

Tools required:

Spanner

- 1. Loosen the cable connection and remove the cable.
- 2. Loosen the clamp.
- 3. Remove the transmitter from the pipe and clean it.

5.3.1.2 Change the O-ring Seal

See section 5.2.1.1: Wetted Part.

5.3.1.3 Mount the Transmitter

See section 3: Installation Instructions.



5.3.2 Blade and Deflector Replacement

The blade is removed when:

- there is a change of pulp type/measuring range
- the blade has been damaged
- service on the measuring part is to be performed

5.3.2.1 Remove the Blade and Deflector

Tools required:

4mm Allen key/hexagon spanner

1. Undo the two screws (1) and remove the deflector (2).



2. Fix the blade (4) in a jaw wise at the same as you hold the transmitter with your other hand to avoid excessive force on the mechanism.



 Undo the two screws (3) that hold the blade and remove it. If the O-ring seal on the measuring module is to be replaced, see section 5.3.5.2: *Mount the New O-Ring Seal*. Otherwise mount the new (or adjusted) blade. See section 5.3.2.2: *Mount*

Otherwise mount the new (or adjusted) blade. See section 5.3.2.2: *Mount the Blade and Deflector.*

5.3.2.2 Mount the Blade and Deflector

Sp	bare	parts	required	d:
----	------	-------	----------	----

Blade

Tools required:

2.5mm Allen key/hexagon spanner

Consumable required:

(Heli-Coil thread inserts)

- 1. Verify that the Heli-Coil thread inserts in the screw holes of the blade are in place.
 - If not, mount new ones.
- Mount the blade onto the spindle. Make sure the transmitter is fixed in the jaw wise during this procedure! Tighten the screws firmly!
- 3. Fit the deflector and tighten it in place with the screws.



NOTE!

If the blade type is changed, or the transmitter's basic adjustment has been changed, a new basic calibration must be made. See section 5.2.3.1: *Basic Force Calibration with JCT-1200*.

4. If the blade type is changed, an update of the transmitter specifications must be performed. See section 5.3.6: *Change Transmitter Specifications*.

5.3.2.3 Mount Transmitter

See Installation Instructions.

5.3.3 Circuit Board Replacement

The circuit board is replaced when:

- The transmitter is not operating properly and the electronics troubleshooting has indicated an error in the circuit board.
- A leakage into the transmitter has occurred that is causing damage to the circuit board. (In this case the measuring unit is probably damaged).
- Over-voltage has caused damage to the circuit board.

NOTE!

If a back-up of all values exist, a change of circuit board can be performed at site.

5.3.3.1 Remove the Circuit Board

Tools required:
Snap ring pliers Small screwdriver 2.5mm Allen key/hexagon spanner ESD protection (Small pliers) (Wise)

- 1. Loosen the four bolts holding the cover and remove the cover.
- 2. Disconnect the cables from their connectors (1) using a small screwdriver.



- 3. Remove the four screws (2) and remove the circuit board (3). Use ESD protection to avoid damaging the circuit board.
- 4. Disconnect the connector from the measuring module on the circuit board.
- 5. Verify that no leakage has occurred. If a leakage is found, locate and eliminate the leakage.

5.3.3.2 Mount the Circuit Board

Spare parts required:		
Circuit board		
Tools required:		
Snap ring pliers 2.5mm Allen key/hexagon spanner (Small pliers) (Wise)		
Consumable required:		
Locking paint Silicone grease		

1. Insert the five cables through the hole in the circuit board.

- 2. Mount the circuit board using the four screws. Lock the screws holding the card with locking paint.
- 3. Connect the cables according to the following connection table:

Chassis Connector	Color	Terminal block	Position on terminal blocks
1	Brown	SK1	1
2	White	SK1	2
3	Blue	SK1	3
4	Black	SK2	1
5	Grey (green/ yellow) ^(a)	SK2	2

(a) Depending on manufacturer there can be different color coding.

4. Mount the cover using the four bolts.

5. Enter all values from the noted back-up or make a basic adjustment of the transmitter. See section 5.2.3.1: *Basic Force Calibration with JCT-1200*.

5.3.4 Measuring Module Replacement

The measuring module is replaced when:

- The blade has been exposed to severe external forces and the measuring module settings are distorted and can not be adjusted correctly.
- The differential transformer is damaged.
- The troubleshooting of the electronic indicates an error in the measuring module.

NOTE!

The measuring module must not be repaired or adjusted! The module is delivered as a complete spare part. A faulty measuring module MUST be sent to BTG for factory repair.

It is worth sending a faulty measuring module to BTG for repair rather than discarding the unit, as the measuring module is the most expensive part of the transmitter. Contact your local BTG dealer.

5.3.4.1 Remove the Measuring Module

Tools required:

Snap ring pliers 2.5 mm Allen key/hexagon spanner 4 mm Allen key/hexagon spanner (Small pliers) (Wise)

- 1. Remove the blade. See section 5.3.2.1: Remove the Blade and Deflector.
- 2. Remove the housing cover.
- 3. Remove the circuit board. See section 5.3.3.1: Remove the Circuit Board.
- 4. Remove the 3 bolts (1) at the bottom of the transmitter housing.



- 5. Carefully extract the measuring module (2).
- 6. Send the measuring module to BTG for factory repair. Contact your local BTG dealer.

5.3.4.2 Change the O-ring Seal

See section 5.2.1.2: Housing.

5.3.4.3 Mount the Measuring Module

Sı	bare	parts	rea	uired:	
-	puio	paito		an oa.	

Measuring module complete

Tools required:

Snap ring pliers 2.5mm Allen key 4 mm Allen key (supplied in transmitter delivery) (Small pliers)

Consumable required:

Locking paint Silicon grease Loctite 222

1. Insert the measuring module into the housing.



NOTE!

Position the measuring module so that the deflector ridge is on the same side of the housing as the cable connection.

- 2. Tighten the three bolts slightly.
- 3. Mount the blade temporarily.
- Align the blade with the housing. Use a ruler on the flat area on the housing.
- 5. Tighten the three bolts hard. Secure the three bolts using a weak type of locking fluid (Loctite 222).
- 6. Mount the circuit board. See section 5.3.3.2: Mount the Circuit Board.
- 7. Mount the housing cover.
- 8. Mount the blade. See section 5.3.2.2: Mount the Blade and Deflector.
- 9. Make a basic adjustment. See section 5.2.3: *Calibration of Transmitter* or section 5.2.3.2: *Basic Force Calibration with SPC-1000*.

5.3.5 Measuring Module O-Ring Seal Replacement

NOTE!

Replacing this O-ring seal is complicated, because it have impact on the transmitters calibration. This should be done by BTG qualified personnel.

The O-ring seal in the measuring module is used to prevent fibers and other impurities penetrating and blocking the spindle movement. Note that fluid is allowed enter the cavity behind the O-ring, but not any further. This does not affect the transmitter performance.

The standard O-ring seal is made of a fluorine-type rubber material developed for the pulp and paper industry and have an extremely high resistance to all chemicals.

As an option the O-ring seal is available in EPDM quality. EPDM is recommended in applications where the pH level is high (more than 12), for example unwashed sulfate pulp, or hydro peroxide (H_2O_2) bleach plant applications with high pH.

The O-ring seal is a low cost spare part and it is easy to replace. It should be replaced as a preventive action when aggressive chemicals are present and also when very reliable measurements are required.

The O-ring seal is replaced when:

 The transmitter is gradually drifting and has lost sensitivity. The rubber in the O-ring seal has been chemically attacked and lost its original properties. Verify that correct quality is used.

NOTE!

Drift can occur for numerous reasons; change of fiber type, freeness level, temperature, flow velocity, or other process related parameters.

5.3.5.1 Remove the O-Ring Seal

Tools required:

Snap ring pliers 2.5mm Allen key 4 mm Allen key (supplied in transmitter delivery) (Small pliers)

- 1. Remove the blade. See section 5.3.2.1: Remove the Blade and Deflector.
- 2. Remove the three screws (1) holding the washer (2) in front of the O-ring seal. Use a screwdriver to carefully bend out the washer.



- 3. Remove the O-ring seal with a small screwdriver. Discard the old O-ring.
- 4. Clean the O-ring cavity using a solvent and pressurized air.
- 5. Verify that the spindle is centred in the surrounding hole. The clearance between the spindle and the surrounding hole in the measuring module should be between 0.07 and 0.1 mm.

NOTE!

If there is no clearance between the spindle and the surrounding hole in the measuring module, the complete measuring module must be replaced. See section 5.3.4.1: *Remove the Measuring Module*.

5.3.5.2 Mount the New O-Ring Seal

Spare p	parts required:	
<u> </u>		

O-ring seal

Tools required:

Pipe, plastic

Consumable required:

Locking paint Silicon grease

Loctite 222

- 1. Inspect the new O-ring seal to ensure the quality is acceptable (no burrs or other deformations).
- 2. Lubricate the O-ring seal lightly using silicon grease or vaseline on the inside and outside.
- 3. Note the Raw signal in the Shear force trim window in the JCT-1200.
- Fit and the O-ring seal onto the spindle and push it down.
 Use a plastic pipe with an inner diameter of 14 mm and outer diameter of 20 mm (approximately 60 mm long) to push the O-ring seal into its cavity.

NOTE!

There should be no sharp edges on the end of the pipe. This could ruin the O-ring seal.

5. Move the spindle in the measuring direction.

If the value has changed more than approximately 4.0 units, use a screwdriver to lift the O-ring, turn it slightly in a single direction, and use the pipe to press down the O-ring seal again.

Remove the pipe and verify the reading again. It is possible to adjust it by "turning" the O-ring. Repeat this action by turning the O-ring in the one single direction until the reading is within the tolerance.

6. Fit the washer in front of the O-ring seal and tighten it with the three screws.

NOTE!

Make sure the screws are equally tightened so that the force on the O-ring seal is even as the washer pushes it down.

- Verify the reading to make sure it is within ±8.0 units. If it more than ±8.0 units, loosen the screws slightly, turn the washer, and re-tighten the screws.
- 8. Mount the blade on the transmitter. See section 5.3.2.2: *Mount the Blade and Deflector.*
- 9. Make a basic calibration of the transmitter. See section 5.2.3.1: *Basic Force Calibration with JCT-1200.*

5.3.6 Change Transmitter Specifications

- 1. Press the Menu (F1), step down through the menu tree to General Settings.
- 2. Select a parameter to edit. Press the **Edit (F3)** key. The menu bar changes.
- 3. Select the Tag or Serial No. Press Edit (F3).
- 4. Enter appropriate value. Press OK (F1).

5.3.7 Change Connector

Spare parts required:
Chassis connector
Tools required:
Snap ring pliers 2.5mm Allen key 4 mm Allen key (Small pliers)
Consumable required:
Locking paint Silicon grease Loctite 222
1. Loosen the four screws and remove the cover.

- 2. Disconnect the connector cables from the circuit board.
- 3. Remove the connector from the housing.
- 4. Mount the new connector.
- 5. Pull the cables up through the hole in the circuit board.
- 6. Connect the connector cables according to the table below

Chassis Connector	Color	Terminal block	Position on terminal block
1	Brown	SK1	1
2	White	SK1	2
3	Blue	SK1	3
4	Black	SK2	1
5	Grey (green/ yellow) ^(a)	SK2	2

(a) Depending on manufacturer there can be different color coding.

7. Mount the cover.

5.4 Troubleshooting

Symptom	Probable Cause	Action
1. SBT-2400 output does not corre-	1.1. Cabling problems	Verify that all cables are connected correctly and that the cables are OK.
consistency	1.2. Damaged blade	Check if the blade is damaged. Remove the transmitter from the stud and mount it in its calibration stand. Remove the blade and mount a new, or corrected, blade on the transmitter. Make a basic force calibration.
		If there are no changes in the output, change the measur- ing unit.
	1.3. Damaged measuring unit	Check if the transmitter responds to calibration. Remove the transmitter from the stud and mount it in its calibration stand. Use different weights to determine if there are changes in the output.
		If there are no changes in the output, change the measur- ing unit.
2. SBT-2400 output does not corre- spond to lab con- sistency values	2.1. Calibration needed	Remove the transmitter from the stud and mount it in its calibration stand. Make a basic force calibration.
sistency values	2.2. Damaged blade	Check if the blade is damaged. Remove the transmitter from the stud and mount it in its calibration stand. Remove the blade and mount a new, or corrected, blade on the transmitter. Make a basic force calibration.
		If there are no changes in the output, change the measur- ing unit.
	2.3. Damaged measuring unit	Check if the transmitter responds to calibration. Remove the transmitter from the stud and mount it in its calibration stand. Use different weights to determine if there are changes in the output.
		If there are no changes in the output, change the measur- ing unit.
3. SBT-2400 is mea- suring correctly but	3.1. Junction box, circuit board, or wiring is faulty	Verify that all wires are connected properly. Open the housing and check all wire connections.
not respond to the		If all wires are connected correctly, check junction box.
operator input		If fault not found in junction box, change the electronics unit.

Symptom	Probable Cause	Action
 4. SBT-2400 oper- ates in a normal manner, except the HART interface. 4.1. Transmitter software is not responding 		Reboot the transmitter. Disconnect the cable to the transmitter. Wait 10 seconds. Reconnect the cable. Is HART working now? If not, go to next problem cause.
	4.2. Faulty electronics unit	Verify the following: - The measuring resistor must be 250 ohm minimum. - The supply voltage is high enough. - The terminal voltage is 11V minimum Does HART operate at any signal current? If it does, try changing the cable. If that does not work, or HART does not operate at all, change the electronics unit.

5.4 - Troubleshooting

6 Parts List

6.1 Spare Parts



ltem No.	Rec. spare parts	Qty	Part No.	Spare Part	Description
1		1	A0065284	Housing cover	
2		1 Alt.	82142639 B0020552	Measuring module	SS steel 254 SMO
3		1	A0065250	Housing	
4		1	14428775	Deflector, blade A, B, and D	SS steel
		1 Alt.	A0068866 B0020511	Deflector, blade C	SS steel 254 SMO
5	*	1	A0065508	Circuit board	
6		1	A0003905	Blade A	SS steel
		1	A0004457	Blade B	SS steel
		1 Alt.	A0083998 B0020503	Blade C	SS steel 254 SMO
		1	A0087981	Blade D	SS steel
7		1	46031001	Chassis connector	Complete with O-ring, not shown in figure
8		1	27008937	O-ring seal, wetted part	EPDM
9			27003151	O-ring seal, housing cover	EPDM
10		1	27000876	O-ring seal, housing	Viton
11		1 Alt.	27012640 27007533	O-ring seal, measuring module	Viton (standard) EPDM (option)
12			46031019	Cable, SBT to JCT-1200	Not shown in figure
13			A0080960	Quick Reference Guide	Not shown in figure



6.2 Optional Accessories

ltem No.	Rec. spare parts	Qty	Part No.	Part Name	Description
1		1	83320358	Welding jig	Not shown in figure
2		1 Alt.	94411006 A0013631	Weld-in stud, complete	SS Steel 254 SMO
3		1	A0082651	FCI-1000	Fieldbus communication interface, not shown in figure
4		1	93253847	SPC-1000/A	
5		1	A0052266	Field Calibration Kit	
6		1 Alt.	A0003509 B0020495	Pipe deflector	SS steel 254 SMO

7 Appendix

7.1 Process Site Selection

When a process site is selected for installation there are several things to consider. This chapter gives guidelines on how to select the best process site to place the transmitter, and when flow guides and deflectors should be used.

There is a risk in certain installations that foreign objects such as large knots or incompletely dissolved pulp lumps, could damage the transmitter blade. To minimize possible damage, a deflector should be welded into the piping upstream of the transmitter.

The transmitter can be installed in a vertical, horizontal, or sloping process line. If the transmitter is installed in a horizontal or sloping process pipe, it must be mounted on the side of the pipe. Any other form of mounting must be avoided due to the risk of air bubbles that disturb measurement. See Fig 1.

Fig 1 Mounting alternatives for the SBT-2400



Never install the transmitter in a pipe section with turbulent flow. Verify that the straight pipe sections upstream and downstream of the transmitter are long enough.

In order to accurately calibrate the transmitter with high accuracy the sampling valve must be mounted as close to the transmitter as possible. The recommendations made regarding damping zones for transmitter mounting also apply to the sampling valve. This enables disturbances from pipe bends, pumps etc. to be avoided.

7.1.1 Straight Pipe Length Calculation

The nomogram in Fig 2 shows the recommended lengths of straight pipe at different operating flow velocities and consistency levels when a chemical pulp is in use. Multiply the relative length (L/D) with the tube diameter (D) to get the minimum length.

For mechanical pulp, the straight pipe length must be multiplied by 1.25.

Straight pipe length formula:



Fig 2 Nomogram

SBT-2400 Appendix ©BTG 2006

Vertical Pipe Installation 7.1.2

The following installation scenario is recommended.

Calculation example for a vertical pipe:



M2041/5en

Fig 3 Transmitter

Horizontal Pipe Installation 7.1.3

If there is no vertical pipe section with the correct length, a horizontal installation on the side is recommended.

Note that the straight section must be 50% longer than the vertical example (Ic constant).

Calculation example of a horizontal pipe:

```
D = 200 \text{ mm}
Cs = 3.5\%, chemical pulp
V = 2.4 \text{ m/s}
The nomogram shows a relative length (L/D) \,\thickapprox\, 7.5. The Mp constant is 1 and the Ic constant is 1,5.
LB = L/D \times D \times Mp \times Ic
LB = 7.5 \times 200 \times 1 \times 1.5 = 2250 \text{ mm}.
LA = 0.5 \times LB
LA = 1125 \text{ mm}
```

The recommended length upstream of the transmitter is 2250 mm and the recommended length downstream of the transmitter is 1125 mm.





7.1.4 Multiple Bend Piping Installation

If there are multiple bends upstream of the transmitter, then the LD must be equal to L or longer. If not, flow guides must be installed.

Two successive pipe bends can also create as twisting flow that cannot be straightened, even if the recommended straight sections are used.

Calculation example for pipe with multiple bends



7.1.5 Valve and Pump Influences

If a valve is mounted directly after a pump, the flow characteristics from the pump are influenced. The axis of the butterfly valve should be parallel to the axis of the pump for best flow results.

A control valve can cause the pulp to thicken. The thickening effect is dependent on the type of pulp and its consistency, and varies with flow rate. If the transmitter is installed too close to a pump or a valve, the output signal from the transmitter will be flow dependant.



Fig 6 Valve influence

7.2 Flow Guide and Pipe Deflector Installation

In some installations there is not possible to have a straight length of pipe upstream of the transmitter that is long enough, or there can be a spiral flow. A flow guide must then be installed upstream of the transmitter.

In other applications there is an unavoidable risk that foreign objects, such as fragments of knots, incompletely dissolved pulp lumps etc., could damage the transmitter. To minimize the risk, a deflector should be installed upstream of the transmitter.

A reversal of flow can also damage the transmitter. If a reverse flow is possible, the installation must be completed with a reverse flow deflector located downstream of the transmitter.

NOTE!

Flow guides will act as deflectors and therefore it is not necessary to install both. If flow guides are needed, it is only necessary to install the flow guides, not any deflectors.

7.2.1 Pipe Deflector Installation

See Fig 7 where to place the deflector. The alternative A is included in a standard delivery but making a deflector like alternative B will work fine. For welding instructions, see section 3.3.2: *Pipe Deflector*.



Fig 7 Pipe deflectors

7.2.2 Flow Guide Installation

See Fig 8 for the arrangement and size of the flow guides. For pipes smaller than 250mm, the size of the flow guides must not be less than 100mm. For welding instructions, see section 3.3.2: *Pipe Deflector*.



7.2.3 Reverse Flow Installation

When there are risk for reverse flow, it is important to protect the transmitter with reverse flow deflectors. The deflectors can be of the same type as used upstream of the transmitter. If a flow guide is mounted, it will also act as a deflector and the same type can be used downstream. For welding instructions, see section 3.3.2: *Pipe Deflector*.





8 Arrangement of flow

guides.

Fig

7.3 Dilution

NOTE!

Calculate the dilution water control valve correctly and use a high quality precision actuator. Make sure that the dilution water pressure is stable and that the water is injected at high velocity into the pump suction.

Correct dilution is essential to ensure reliable transmitter operation!

Dilution water should be pressure-controlled or otherwise protected from major pressure variations.

To ensure good control, dilute no more than 20% in each dilution stage, though a higher percentage may be acceptable early in the process.

If considerable dilution is required it should be carried out in two stages, 70% to 80% of the water being added in the bottom part of the pulp chest and the remainder in the form of a fine dilution upstream of the pump.

To avoid consistency variations, thoroughly mix the bottom of the pulp chest upstream of the transmitter.

The dilution water pipe should be inserted in such a way that it extends 15-50 mm (0.6-2 in), depending upon pipe size, into the main pipe on the suction side of the pump, see Fig 10. The pipe must be inserted perpendicular to the suction stud. The pipe should be located at 1/3 of the distance between the pump and the chest, measured from the pump, to avoid back flow into the chest.

At the point of injection, the dilution water pipe should be dimensioned to produce a rate of flow 3–4 times faster than the flow in the main pipe. Typically this means a dilution water flow 3–5 m/s (10–16.5 fps) at max flow in the suction pipe. The dilution water pipe should have the same or larger dimension as the valve bore to prevent the valve being plugged by pulp at water pressure loss.

Choose a dilution water valve with linear characteristics. The pressure drop over the valve should be at least 0.5 bar (7 psi) and should exceed 25% of the total pressure drop in the dilution water line. The valve and its actuator must operate with the least possible backlash and smallest possible dead zone. The valve must be tight when in its closed position, see Fig 10.

NOTE!

Additional information in *"Accurate Consistency — a hand-book in consistency measurement in pulp and paper processing"*— available from BTG.

Fig 10 Dilution water supply at consistency control

 $\begin{array}{l} \Delta \, p = \text{Dilution water pressure} \\ \text{difference, upstream /} \\ \text{downstream of the dilution water} \\ \text{valve} \\ \text{V1 = Velocity: 3-5 m/s, (10-16.5 fps)} \\ \text{V2 = Typically 2-3 m/s (6.5-9.8 fps) for normal consistency} \\ \text{installations} \\ \text{G = Min. 15-50 mm / 0.6-2 inches} \\ \text{depending upon suction pipe size} \\ \Delta \, p = \text{min. 0.5 bar / 7 psi} \end{array}$

L =See fig 7 on page 61

A =Recommended design B/C=Not recommended



Location of the dilution water valve:

The conventional method is to install the valve above the highest pulp level in the chest, to prevent pulp from entering the valve during a shutdown. With modern large chests it is not always possible to meet this requirement.

NOTE!

Do not use saddles in dilution water piping, see Fig 10 (B).

NOTE!

We recommend locating the valve as close as possible to the suction pipe wall.

7.4 Dimensioning of the Dilution Water Valve

Calculation of dilution water quantity – Q Required data: Production [t/h] = P Uncontrolled consistency [%] = C1 Desired controlled consistency [%] = C2

7.4.1 Calculation Formula for Dilution Water Flow:

 $\frac{P\times 100(C1-C2)}{C1\times C2} = Q \quad \text{m}^3\text{/h}$

Example:

Production = 8 t/h

Uncontrolled consistency = 3%

Desired controlled consistency = 2.5%

$$Q = \frac{8 \times 100(3-2,5)}{3 \times 2,5} = \frac{800 \times 0,5}{7,5} = 53,3 \text{ m}^3/\text{h}$$

7.4.2 Dimensioning of the Dilution Water Valve

Calculation formula for the capacity factor K_v.

$$\mathbf{K}_{\mathbf{v}} = \mathbf{Q} \sqrt{\frac{\rho}{1000 \times \Delta_{\mathbf{p}}}}$$

NOTE!

 $C_v = K_v \times 1.155$

- $\mathbf{K}_{\mathbf{v}}$ = Capacity factor (m³/h)
- \mathbf{Q} = Quantity of liquid (m³/h)
- ρ = Density of liquid (kg/m³)

 $\boldsymbol{\Delta}_{\boldsymbol{p}}$ = Pressure drop across the control valve (bar)

When the dilution water density normally is 1000 kg/m³ the formula can be simplified to:

$$\mathbf{K}_{\mathbf{v}} = \frac{\mathbf{Q}}{\sqrt{\Delta \mathbf{p}}}$$

The pressure of the dilution water should not vary more than 15%. In case of large pressure variations we recommend pressure control of the dilution water.



EXAMPLE:

In a traditional installation as shown in Fig 11, dilution water is injected before the pulp pump and the pressure drop across the control valve is equal to the difference between the dilution water pressure and the height of the pulp chest. The minimum pressure difference should be 0.4 - 0.5 bar / 6 - 7.5 psi.

In this case the pressure difference is 0.8 - 0.3 bar = 0.5 bar / 12 - 4.5 psi = 7.5 psi. Using the same data as in the examples above, the required Kv will be:

$$K_{v} = \frac{Q}{\sqrt{\Delta p}} = \frac{53,3}{\sqrt{0,5}} = 75,4$$

Choose a value size 40 or 50 mm (1½ or 2 in) depending on the pipe dimension.

The velocity of the dilution water at the point of injection should be 3 - 5 m/s (10 - 16.5 fps). According to the nomogram in Fig 12 a pipe size of 60-80 mm (2.5 - 3.2 in) is a suitable dimension.




A correction factor must be applied when the valve is smaller than the supply pipe.

When dimensioning the valve a correction factor must be included for the reduction from a larger supply pipe to a smaller valve, see Fig 13. The calculated capacity factor K_v (C_v) is multiplied by the correction factor. The correction factor is determined by the degree of reduction.





NOTE!

Use the curve for 85° valve opening when calculating the correction factor.

EXAMPLE:

Calculated K_v -value = 75.4

Pipe line dimension = 60 mm. (D)

Selected valve size 50 (d)

which has a K_v -value of 130 at 75° opening.

Check that selected valve K_v is sufficient, see Fig 15.

 $\frac{D}{d}$ = 1.2 which gives a correction factor of 0.78

The valve K_v will be 0.80 x 130 = and the valve size 50 is sufficient.



Example shown in Fig 14:

Q = 6000 m³ / 24 h

Pipe diam. = 300 mm

Thus velocity in the pipe line is:

$$\frac{Q}{t} = \frac{6000}{24 \times 60} = 4.17$$
 m³/min.

In the nomogram (Fig 14) we can see that the flow velocity is \approx 0.98 m/s (\approx 3.2 fps)

7.5 Pressure and Temperature Limits

Pressure and temperature limits for piping, pipe flanges and fittings of stainless steel — according to Swedish Standard SMS 1233:

For conversion to SI-units: 1 at \approx 9.8 N/cm²

Maximum operating pressure:

Maximum operating pressures under normal conditions are given in the table below. The values stated must not be exceeded by more than 5%. However, the operating pressure must never exceed the nominal pressure (PN).

The diagram in Fig 15 shows maximum operating pressure for different pressure classes at different operating temperatures.

Stainless steel En 14404 according to SS 142343 (SS 316L).

EXAMPLE:

What is maximum operating pressure at 100°C operating temperature and pressure class PN 10?

Answer: 8 ato \approx 8 bar.

Fig 15 Max. operating pressure at different operating temperatures

PN	Operating temperature °C														
	0-20	30	40	50	60	70	80	90	100	120	140	160	180	200	250
6	6	5.5	5.5	5.5	5	5	5	5	4.5	4.5	4.5	4.5	4.5	4	4
10	10	9.5	9.5	9	9	8.5	8.5	8.5	8	8	7.5	7.5	7.5	7	7
16	16	15.5	15.0	14.5	14	14	13.5	13.5	13	12.5	12.5	12	12	11.5	11
25	25	24	23.5	23	22	22	21.5	21	20.5	19.5	19	18.5	18.5	18	17.5

(ato = atmosphere (atm) overpressure)

7.6 Menu Overview (only in English)

7.6.1 Measurement/Sampling



Range 1



Std err 0.0 2 active sample(s)

Back Save

0.06

Cancel

7.6.2 Calibrate

7.6.3 Configure

	Measurement Calibrate	
	Diagnostics	
	Enter	
	Configure	
	General settings	
	Shear force trim	
	Analog output trim	
	Menu Enter	
		1
Comonal anthings	Shear force trim	Analog output trim
LabSamplTime: 20 sec	Mounted+air: 931	Analog output tilm
LcdBackLight: 0 sec	Blade: 1230	4 mA trim: 0
Blade type: A	Blade+weight: 1672	20 mA trim: 16383
Tag: SBT-TAG	Paw signal 025 /	Test output: 12.00 mA
Serial No: 1234567890	Raw sig trim: 15	
Menu Edit	Menu Edit	Menu Test Edit

7.6.4 Diagnostics



Diagnostics

Diagnostics									
Temp	35°C	95°F							
Peak temp	40°C	104°F							
Software v Running ho Program st Menu	1.00 32 5								

7.7 Blade Selection Guide

To be able to choose an appropriate blade, use the table below.

		Blade A		Blade B		Blade C		Blade D		
Puln tvi	ne	Flow lim 0.5 - 5 m dependi pulp typ	its: /s ng on e	Flow lim 0.5 - 5 m dependin pulp typ	its: /s ng on e	Flow lim 0.5 - 5 m dependin pulp type	its: /s ng on e	Flow limits: 0.5 - 5 m/s depending on pulp type		
rup type		Cons: 1.5 - 7% dependi pulp typ	ng on e	Cons: 2 - 8% depending on pulp type		Cons: 4 - 16% depending on pulp type		Cons: 1.5 - 8% depending on pulp type		
		K1	K2	K1	K2	K1	K2	K1	K2	
HWB	Hardwood, bleached Short-fiber chemical pulp bleached.	0.9959	0.4461	1.6912	0.3429	2.3736	0.4139	1.2925	0.3523	
HWU	Hardwood, unbleached Short-fiber chemical pulp unbleached.	1.1407	0.3508			1.7086	0.4598	1.1831	0.3655	
SWB	Softwood, bleached Long-fiber chemical pulp bleached.	0.8632	0.4318			2.0239	0.4418	0.8930	0.4210	
SWU	Softwood, unbleached Long-fiber chemical pulp unbleached.	0.8539	0.4149			1.3745	0.4903	0.7282	0.4497	
GW	Groundwood					1.8076	0.4534	1.1832	0.3258	
ТМР	Thermo mechanical pulp	0.6665	0.4356			1.7094	0.4581	1.1093	0.3394	
СТМР	Chemical thermo mechanical pulp	0.5030	0.5378			1.7950	0.4552	0.9228	0.3788	
ONP	Recycled old newspaper					2.2047	0.4521	1.2382	0.4069	
000	Recycled old corrugated container					2.0064	0.4447	0.9234	0.4467	